

CONECTOR AND SWITCH
SPAIN

AMBUSCH

COMPONENTS SIDE

- 1 A + 5 VCC
- 2 A + 5 VCC
- 3 A + 12 VCC MECANIC COIN COUNTERS
- 4 A ACELERATOR ONE
- 5 A SHOT ONE
- 6 A ACELERATOR TWO
- 7 A SHOT TWO
- 8 A TWO PLAYERS
- 9 A ONE PLAYER
- 10 A TWO COINS
- 11 A ONE COIN
- 12 A BLUE
- 13 A GREEN
- 14 A RED
- 15 A SYNC
- 16 A + 12 VCC SOUND
- 17 A GROUND SOUND
- 18 A GROUND

SOLDERING SIDE

- 1 B GROUND
- 2 B GROUND
- 3 B + 12 MECANIC COIN COUNTERS
- 4 B UP ONE
- 5 B DOWN ONE
- 6 B LEFT ONE
- 7 B RIGHT ONE
- 8 B UP TWO
- 9 B DOWN TWO
- 10 B LEFT TWO
- 11 B RIGHT TWO
- 12 B COUNTER 1 25
- 13 B COUNTER 1 25
- 14 B COUNTER 2 50
- 15 B SPEAKER RIGHT
- 16 B SPEAKER LEFT
- 17 B + 5 V DC
- 18 B + 5 V DC

(NOTAS)

- 1) + 5 V 4A
- 2) + 12 V SOUND 2A
- 3) SPEAKER 10W RIGHT
- 4) SPEAKER 10W LEFT
- 5) COMMON GROUND BOUTTONS

SW	1	2	
	OFF	OFF	6 SHIPS
	ON	OFF	5 SHIPS
	OFF	ON	4 SHIPS
	ON	ON	3 SHIPS

SW 3 ON
 OFF (PROGRESIVA)

SW 4 ON
 OFF FREE PLAY

	IN(11 A)	IN(10 A)
SW 5 ON	1 CREDIT	2 CREDIT
SW 5 OFF	FIRTS 1 CREDIT	3 CREDIT
	SECOND 2 CREDIT	

SW 6 ON EASY
 OFF DIFFICULT

SW 7 ON 80.000 POINTS EXTRA SHIP
 OFF 40.000 POINTS EXTRA SHIP

SW ON TABLE (JAPAN)
 OFF SPAIN

CONECTOR MONITOR

- 1 -> MASA
- 2 -> VERDE
- 3 -> ROJO
- 4 -> AZUL
- 5 -> N.C.
- 6 -> SINCRONISMO