


## **OPTION SWITCH SETTING**

## DIP SW 2

OPTION				S1	<b>S4</b>	<b>S</b> 5	<b>S6</b>	
		1*	2*	3*				
GAME NUMBER TARGET DIFFICULTY	VERY EASY	7	7	7		ON	OFF	OFF
		7	7	6		OFF	ON	OFF
		.6	7	5		ON	ON	OFF
		6	7	4		OFF	OFF	ON
	NORMAL	5	6	4		OFF	OFF	OFF
		5	5	4		ON	OFF	ON
		5	6	3		OFF	ON	ON.
	VERY DIFFICULT	5	5	3		ON	ON	ON
TEST					ON			

<sup>1\*:</sup>Number of targets regarding the first game. 2\*:Number of targerts regarding the second game.

<sup>3\*:</sup>Number of targets regarding the third game.



Carabina electrónica.