

XXXXX XXXXX
XXXXXX XXXXXX
XXX XXXXX XXX
XXX XXX XXX
XXX X XXX
XXX XXX XXX
XXX XXX XXX

X
XXX
XXXXX
XXX XXX
XXX XXX
XXXXXXXXXXXXX
XXX XXX

XXXXXXXXXXXXX
XXX
XXX
XXX XXXXXX
XXX XXX
XXX XXX
XXXXXXXXXXXXX

XXXXXX XXX
XXXXXXXX XXX
XXX XXX XXX
XXX XXX XXX
XXX XXXXXX
XXX XXXXX
XXX XXXX

XXXXXXXXXXXXX
XXX
XXX
XXXXXXXXXX
XXX
XXX
XXXXXXXXXXXXX

XXXXXXXXXXXXX
XXX
XXX
XXX
XXX
XXX

BEFORE ATTEMPTING TO CONNECT THIS PRODUCT PLEASE READ THESE INSTRUCTIONS.

=====

CAUTION CAUTION CAUTION CAUTION CAUTION CAUTION CAUTION CAUTION

=====

BEFORE CONNECT POWER SUPPLY UNIT BE SURE VOLTAGES ARE IN RANGE
SPECIFIED (SEE TABLE). ADJUST TO NOMINAL VALUES WITH POWER
SUPPLY CONNECTED TO THE CARDS.

=====

CAUTION CAUTION CAUTION CAUTION CAUTION CAUTION CAUTION CAUTION

=====

VOLTAGES TABLE		
min	NOMINAL	max
4.7v	5.0v	5.2v
11.4v	12.0v	12.6v

