



| CARA SOLDADURA | | CARA COMPONENTES |
|-------------------------|---------|-------------------------|
| GND | 1A 1B | GND |
| +5V | 2A 2B | +5V |
| +12V | 3A 3B | +12V |
| GND | 4A 4B | GND |
| (ALTAVOZ) GND | 5A 5B | (ALTAVOZ) GND |
| SALIDA ALTAVOZ | 6A 6B | SALIDA ALTAVOZ |
| CONTADOR DE MONEDAS (-) | 7A 7B | CONTADOR DE MONEDAS (+) |
| | 8A 8B | |
| DISPARO JUG. 1 | 9A 9B | ARRIBA JUG. 1 |
| ABAJO JUG. 1 | 10A 10B | IZQUIERDA JUG. 1 |
| DERECHA JUG. 1 | 11A 11B | GND |
| DISPARO JUG. 2 | 12A 12B | ARRIBA JUG. 2 |
| ABAJO JUG. 2 | 13A 13B | IZQUIERDA JUG. 2 |
| DERECHA JUG. 2 | 14A 14B | GND |
| START 2 JUGADORES | 15A 15B | GND |
| START 1 JUGADOR | 16A 16B | GND |
| ENTRADA DE MONEDA " 1" | 17A 17B | GND |
| ENTRADA DE MONEDA " 2" | 18A 18B | GND |
| N. C. | 19A 19B | LOOPING JUG. 1 |
| N. C. | 20A 20B | LOOPING JUG. 2 |
| N. C. | 21A 21B | GND |
| SINCRONISMOS | 22A 22B | ROJO |
| VERDE | 23A 23B | AZUL |
| N. C. | 24A 24B | N. C. |
| N. C. | 25A 25B | N. C. |
| N. C. | 26A 26B | N. C. |
| +5V | 27A 27B | +5V |
| GND | 28A 28B | GND |

| SWITCH "1" | | OPCIONES | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------------------|---------------------------|----------|-----|---|-----|---|-----|-----|-----|-----|-----|
| ENTRADA DE MONEDAS "1" | PARTIDAS GRATUITAS | | | | | | | | ON | ON | ON |
| | 1 MONEDA / 1 PARTIDA | | | | | | | | OFF | OFF | OFF |
| | 1 " / 2 " | | | | | | | | OFF | OFF | ON |
| | 1 " / 4 " | | | | | | | | OFF | ON | OFF |
| | 2 " / 1 " | | | | | | | | OFF | ON | ON |
| | 2 " / 3 " | | | | | | | | ON | OFF | OFF |
| | 3 " / 1 " | | | | | | | | ON | OFF | ON |
| | 4 " / 1 " | | | | | | | | ON | ON | OFF |
| TIPO | MAQUINA NORMAL (VERTICAL) | | | | | | | ON | | | |
| | MAQUINA DE MESA | | | | | | | OFF | | | |
| AVION EXTRA | 1er. AVION EXTRA A 20.000 | | | | OFF | | | | | | |
| | 1er. AVION EXTRA A 30.000 | | | | ON | | | | | | |
| | AVION EXTRA CADA 80.000 | | | | | | OFF | | | | |
| | AVION EXTRA CADA 100.000 | | | | | | ON | | | | |
| NUMERO DE AVIONES | 1 AVION | OFF | ON | | | | | | | | |
| | 2 " | ON | OFF | | | | | | | | |
| | 3 " | OFF | OFF | | | | | | | | |
| | 5 " | ON | ON | | | | | | | | |

| SWITCH "2" | | OPCIONES | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------------------|----------------------|----------|-----|-----|---|---|-----|---|-----|-----|-----|
| ENTRADA DE MONEDAS "2" | PARTIDAS GRATUITAS | | | | | | | | ON | ON | ON |
| | 1 MONEDA / 1 PARTIDA | | | | | | | | OFF | OFF | OFF |
| | 1 " / 2 " | | | | | | | | OFF | OFF | ON |
| | 1 " / 4 " | | | | | | | | OFF | ON | OFF |
| | 2 " / 1 " | | | | | | | | OFF | ON | ON |
| | 2 " / 3 " | | | | | | | | ON | OFF | OFF |
| | 3 " / 1 " | | | | | | | | ON | OFF | ON |
| | 4 " / 1 " | | | | | | | | ON | ON | OFF |
| PANTALLA | NORMAL | | | | | | OFF | | | | |
| | INVERTIDA | | | | | | ON | | | | |
| PANTALLA | PARO DE IMAGEN | ON | | | | | | | | | |
| | NORMAL | OFF | | | | | | | | | |
| DIFICULTAD | NORMAL | | OFF | OFF | | | | | | | |
| | ↓ | | OFF | ON | | | | | | | |
| | | | ON | OFF | | | | | | | |
| | MAXIMA DIFICULTAD | | ON | ON | | | | | | | |