

COVIELSA

LOTO-PLAY 90

-Tabla de combinaciones de creditos:

SWITCH				MON. 1	MON. 2
4	3	2	1		
ON	ON	ON	ON	1/1	1/2
ON	ON	ON	OFF	1/1	1/3
ON	ON	OFF	ON	1/1	1/4
ON	ON	OFF	OFF	1/1	1/5
ON	OFF	ON	ON	1/2	1/2
ON	OFF	ON	OFF	1/2	1/3
ON	OFF	OFF	ON	1/2	1/4
ON	OFF	OFF	OFF	1/2	1/5
OFF	ON	ON	ON	2/1	1/1
OFF	ON	ON	OFF	2/1	1/2
OFF	ON	OFF	ON	2/1	1/3
OFF	ON	OFF	OFF	2/1	1/4
OFF	OFF	ON	ON	3/1	1/1
OFF	OFF	ON	OFF	3/1	1/2
OFF	OFF	OFF	ON	4/1	1/1
OFF	OFF	OFF	OFF	4/1	1/2

-Tabla de porcentajes de loteria:

SWITCH	PORCENTAJE
8 7	
ON ON	2 %
ON OFF	5 %
OFF ON	7 %
OFF OFF	10 %

-Los switch 5 y 6 no se utilizan.

